


GAMING DESK

Assembly instructions
Instructions de montage
Instrucciones de montaje
Anleitung zur Montage



① x 6

② x 8


③ x 12

④ x 2


⑤ x 4

⑥ x 6


⑦ x 1



M8x50




M8x12




M6x16




M6x20




A x 1




B x 1



C x 2




D x 1




E1 x 1




E2 x 1




E3 x 1




F x 2



G x 1















H x 1





I x 4





7 Optional mouse pad
Tapis de souris optionnel
Alfombrilla de ratón opcional
Optionales Mauspad



CONTACT & SUPPORT



SUBSONIC
314, allée des noisetiers
69760 Limonest - France
contact@subsonic.com
www.subsonic.com



WWW.SUBSONIC.COM